

Euro Mini Bako S auto-clean

Daily cleaning procedure

STEP 1



Place waste buckets under nozzle

STEP 2



Remove connector with suction tube attached, place into cleaning bucket.

STEP 3



Detach connector and suction foot, wash thoroughly under hot running water and re-assemble.

STEP 4




Fill cleaning bucket to level line with **hand hot water (around 50°C)**.

STEP 5



Reconnect assembled tube, place suction foot into cleaning bucket.

STEP 6



Press cleaning button once. Auto-pre-rinsing begins (2 mins).

STEP 7



After cycle remove cream nozzle and place into cleaning bucket. Attach cleaning nozzle.

STEP 8



Wash cream nozzle under hot running water and place into cleaning bucket

STEP 9




Fill cleaning bucket to level line with **hand hot water (around 50°C)**. Add two pumps of DCA auto clean sanitiser

STEP 10



Place suction foot into cleaning container. Press cleaning buttons once. Auto sanitising begins (2 mins)

STEP 11



Rinse cleaning bucket and cream nozzle. Fill cleaning bucket to level line with **clean cold water**.

STEP 12



Press cleaning button once. Auto-final rinse begins (2 mins).

STEP 13



After cycle remove cleaning nozzle and re-attach cream nozzle.

STEP 14



Wash both buckets and cleaning nozzle, rinse and suitably store.

STEP 15



Wipe all machine and local work surfaces clean.

STEP 16



Machine is ready for use