

## Cremaldi Auto-Clean 1.5-ltr Cream Machine Daily cleaning procedure

### STEP 1



Remove lid, lift suction pipe, remove and wash container. Place waste bucket under nozzle.

### STEP 2



Wipe suction pipe with a clean paper towel.

### STEP 3



Fill container with **hand hot water (around 50°C)**.

### STEP 4



Place container into machine and swing suction pipe down.

### STEP 5



Press cleaning button once. Auto-pre-rinsing begins (2 mins).

### STEP 6



After cycle remove cream nozzle and place into container. Attach cleaning nozzle.

### STEP 7



Wash cream nozzle under hot water. Fill container with **hand hot water (around 50°C)**.

### STEP 8



Add two full pumps of DCA Auto-Clean Sanitiser.

### STEP 9



Place container into machine and swing suction pipe down.

### STEP 10



Press cleaning button once. Auto-sanitising begins (2 mins).

### STEP 11



Rinse container and cream nozzle. Fill container with **clean cold water**.

### STEP 12



Place container into machine and swing suction pipe down.

### STEP 13



Press cleaning button once. Auto-final-rinse begins (2 mins).

### STEP 14



After cycle remove cleaning nozzle. Re-attach cream nozzle. Remove container.

### STEP 15



With a sanitised paper towel, wipe all machine and local work surfaces clean. Wipe dry with a clean towel.

### STEP 16



Return container to machine. Replace lid.



THE CREAM WHIPPING SPECIALIST

# Cremaldi Auto-Clean 1.5-ltr Cream Machine

## Daily cleaning procedure

### What you need – tools



Blue paper towel



Container



DCA Auto-Clean Sanitiser  
with dosage pump



Waste bucket



Cleaning nozzle