

# Euro Amigo 1.5L

## Daily cleaning procedure

STEP 1



Remove lid, whilst lifting suction pipe wipe clean.

STEP 2



Remove and wash cream container. Place waste bucket under nozzle.

STEP 3



Fill cleaning bucket to level line with **hand hot water (around 50°C)**.

STEP 4



Place container into machine and swing the suction pipe down

STEP 5



Pre-rinsing stage: intermittently pulse machine until cleaning container is empty

STEP 6



After cycle cream nozzle and place into container. Attach cleaning nozzle.

STEP 7



Wash cream nozzle under hot water. Fill container with **hand hot water (around 50C)**

STEP 8



Add two full pumps of DCA auto-clean sanitiser

STEP 9



Place container into machine and swing suction pipe down

STEP 10



Sanitising stage: intermittently pulse machine until cleaning container is empty

STEP 11



Rinse container and cream nozzle. Fill container with **cold water**

STEP 12



Place container into machine and swing suction pipe down

STEP 13



Final rinsing stage: intermittently pulse until the container is empty

STEP 14



After cycle remove cleaning nozzle. Re-attach cream nozzle. Remove cleaning nozzle

STEP 15



Wipe all machine and local work surfaces clean.

STEP 16



Return cream container to machine and replace lid