

## Amigo 1.5-ltr Cream Machine Daily cleaning procedure



**STEP 1**

Remove lid, lift suction pipe, remove and wash container. Place waste bucket under nozzle.



**STEP 2**

Wipe suction pipe with a clean paper towel.



**STEP 3**

Fill container with **hand hot water (around 50°C)**.



**STEP 4**

Place container into machine and swing suction pipe down.



**STEP 5**

Pre-rinsing stage – intermittently pulse machine until container is empty.



**STEP 6**

After pre-rinse, remove cream nozzle and place into container. Attach cleaning nozzle.



**STEP 7**

Wash cream nozzle under hot water. Fill container with **hand hot water (around 50°C)**.



**STEP 8**

Add two full pumps of DCA Auto-Clean Sanitiser.



**STEP 9**

Place container into machine and swing suction pipe down.



**STEP 10**

Sanitising stage – intermittently pulse machine until container is empty.



**STEP 11**

After sanitising stage, rinse container and cream nozzle. Fill container with **clean cold water**.



**STEP 12**

Place container into machine and swing suction pipe down.



**STEP 13**

Final rinsing stage – intermittently pulse machine until container is empty.



**STEP 14**

After final rinsing stage, remove cleaning nozzle, re-attach cream nozzle and remove container.



**STEP 15**

With a sanitised paper towel, wipe all machine and local work surfaces clean. Wipe dry with a clean towel.



**STEP 16**

Return container to machine. Replace lid.



THE CREAM WHIPPING SPECIALIST

# Amigo 1.5-ltr Cream Machine

## Daily cleaning procedure

### What you need – tools



Blue paper towel



Container



DCA Auto-Clean Sanitiser  
with dosage pump



Waste bucket



Cleaning nozzle