

Cremaldi auto-clean 6L Daily cleaning procedure

STEP 1



Remove lid, whilst lifting suction pipe wipe clean.

STEP 2



Remove and wash cream container. Place waste bucket under nozzle.

STEP 3



Fill cleaning bucket to level line with hand hot water (around 50°C).

STEP 4



Place cleaning bucket into machine and swing suction pipe down

STEP 5



Auto pre-rinsing begins (2 mins).

STEP 6



After cycle remove cream nozzle and place into cleaning bucket.
Attach cleaning nozzle.

STEP 7



Wash cream nozzle under hot water. Fill cleaning bucket to level line with hand hot water (around 50°C).

STEP 8



Add two full pumps of DCA Auto-Clean sanitiser

STEP 9



Place cleaning bucket into machine and swing suction pipe down

STEP 10



Press cleaning button once. Auto-sanitising begins (2 mins)

STEP 11



Rinse cleaning bucket and cream nozzle. Fill cleaning bucket to level line with **cold water**.

STEP 12



Place cleaning bucket into machine and swing suction pipe down

STEP 13



Press cleaning button once. Auto final rinsing begins (2 mins)

STEP 14



After cycle remove cleaning nozzle.
Re-attach cream nozzle.
Remove cleaning container

STEP 15



Wipe all machine and local work surfaces clean.

STEP 16



Return cream bowl to machine. Replace lid.