

Euro Piccolo auto-clean 2L Daily cleaning procedure

STEP 1



Remove lid, whilst lifting suction pipe wipe clean.

STEP 2



Remove and wash cream container. Place waste bucket under nozzle.

STEP 3



Fill cleaning bucket to level line with **hand hot water (around 50°C)**.

STEP 4



Place container into machine and swing the suction pipe down

STEP 5



Press cleaning button once. Auto pre-rinsing begins (2 mins)

STEP 6



After cycle cream nozzle and place into container. Attach cleaning nozzle.

STEP 7



Wash cream nozzle under hot water. Fill container with **hand hot water (around 50C)**

STEP 8



Add two full pumps of DCA auto-clean sanitiser

STEP 9



Place container into machine and swing suction pipe down

STEP 10



Press cleaning button once. Auto-sanitising begins (2 mins)

STEP 11



Rinse container and cream nozzle. Fill container with **cold water**

STEP 12



Place container into machine and swing suction pipe down

STEP 13



Press cleaning button once. Auto-final rinsing stage begins (2 mins)

STEP 14



After cycle remove cleaning nozzle. Re-attach cream nozzle. Remove cleaning nozzle

STEP 15



Wipe all machine and local work surfaces clean.

STEP 16



Return cream container to machine and replace lid